

## Quad-Bay B5 Battery Charging Station



Figure 1

### Charging B5 Battery Cartridges

1. Plug the barrel side of the power supply into the charger and plug the power adapter into the wall outlet. If using a flat power supply cable, route the cable through the channel on the left labeled with the number 1. If using a round power supply cable, route the cable through the channel on the right, labeled 2. (Figure 2)



Figure 2

2. Place the battery cartridges into the slots as shown in Figure 3. Each charging slot has a corresponding Charge Indicator LED. When the battery cartridge is seated correctly, the Charge Indicator LED will illuminate green, indicating that the battery cartridge is charging.

**Note:** The Fuel Gauge LEDs on the battery cartridges will flash 4 seconds ON and 2 seconds OFF while charging. Refer to the Fuel Gauge Indicator chart to determine the cartridge battery life status. (Figure 4)




Figure 3

Battery Life	Fuel Gauge Indicators
<10%	● (Flashes Rapidly)
<25%	●
25-50%	● ●
50-75%	● ● ●
75%+	● ● ● ●

Figure 4

code



## Quad-Bay B5 Battery Charging Station



Figure 1

### Charging B5 Battery Cartridges

1. Plug the barrel side of the power supply into the charger and plug the power adapter into the wall outlet. If using a flat power supply cable, route the cable through the channel on the left labeled with the number 1. If using a round power supply cable, route the cable through the channel on the right, labeled 2. (Figure 2)



Figure 2

2. Place the battery cartridges into the slots as shown in Figure 3. Each charging slot has a corresponding Charge Indicator LED. When the battery cartridge is seated correctly, the Charge Indicator LED will illuminate green, indicating that the battery cartridge is charging.

**Note:** The Fuel Gauge LEDs on the battery cartridges will flash 4 seconds ON and 2 seconds OFF while charging. Refer to the Fuel Gauge Indicator chart to determine the cartridge battery life status. (Figure 4)




Figure 3

Battery Life	Fuel Gauge Indicators
<10%	● (Flashes Rapidly)
<25%	●
25-50%	● ●
50-75%	● ● ●
75%+	● ● ● ●

Figure 4

code

